




































H-SMART



					
	Rear wash		Drying		Women Wash

					
					
water flow	stop	position	dryer temperature	stop	

		
		
water flow	stop	position

Icon	Button	Icon	Button
	「Rear wash」 <i>Lavaggio posteriore</i>		「Water pressure adjustment」 <i>Regolazione pressione acqua</i>
	「Lady wash」 <i>Lavaggio femminile</i>		「Nozzle position adjustment」 <i>Regolazione posizione ugello</i>
	「Stop」		「Warm air drying」 <i>Asciugatura aria calda</i>
	「Oscillation massage」 <i>Massaggio oscillante</i>		「Water temperature adjustment」 <i>Regolazione temperatura acqua</i>
	「Pulsing massage」 <i>Massaggio pulsante</i>		